



# Software API

## OPTION 7.2 Interface

## About this document

### Overview and Purpose

This document lists the set of AT commands that are used for connection management with Option 7.2 data cards.

### Confidentiality

All data and information contained or disclosed by this document is confidential and proprietary of Option nv, and all rights therein are expressly reserved. By accepting this document, the recipient agrees that this information is held in confidence and in trust and will not be used, copied, reproduced in whole or in part, nor its contents revealed in any manner to others without prior and written permission of Option nv.

### Version History

Date	Version	Author(s)	Revision(s)	Remarks
Jun 11, 2007	V01 – D1	J. Schrijvers		Initial version
Jan 15, 2008	002ext	J. Schrijvers		Update for AT\$QCPDPP
Jan 17, 2008	003ext	J. Schrijvers		Update for AT_OWANDATA
Nov 17, 2008	004ext	J. Schrijvers		Added AT_OPDPP
Nov 20, 2008	005ext	J. Schrijvers		Updated states for AT_OWANCALL
Jan 21, 2009	006ext	J. Schrijvers		Updated states for AT_OWANCALL
Dec 2, 2009	007ext	J. Schrijvers		Update for AT\$QCPDPP and AT_OPDPP

**Author:** J. Schrijvers

**Creation Date:** Dec 2, 2009

**Option**

**Confidential:** This document is Option Confidential - it may not be duplicated, neither distributed externally without prior and written permission of Option nv.

**Version:** v007ext

**Page:** 1 of 8

## Table of contents

1	INTRODUCTION	3
2	AT-COMMANDS FOR CALL SETUP	4
2.1	Network Call “_OWANCALL”	4
2.2	Network Data “_OWANDATA”	5
2.3	PDP Context Authentication “\$QCPDPP”	6
2.4	PDP Context Authentication “_OPDPP”	7
3	SCENARIO	8

**Author:** J. Schrijvers

**Creation Date:** Dec 2, 2009

**Version:** v007ext

**Page:** 2 of 8

**Option** This document is Option Confidential - it may not be duplicated, neither distributed externally  
**Confidential:** without prior and written permission of Option nv.

## 1 INTRODUCTION

Option 7.2 data cards are cards that contain firmware that supports the WAN interface. This WAN interface is Qualcomm's implementation to get maximum downlink throughput performance on HSDPA 7.2 networks. In order to setup a call with such a data card, a set of AT commands are provided.

**Author:** J. Schrijvers

**Creation Date:** Dec 2, 2009

**Version:** v007ext

**Page:** 3 of 8

**Option Confidential:** This document is Option Confidential - it may not be duplicated, neither distributed externally without prior and written permission of Option nv.

## 2 AT-COMMANDS FOR CALL SETUP

### 2.1 Network Call “\_OWANCALL”

Command	Possible Response(s)
AT_OWANCALL=<c>,<s>,<u>	OK
AT_OWANCALL?	_OWANCALL: <c>,<s>,<u>

#### Description

This commands starts or stops a network call for a specific context. There's also an option to enable unsolicited notification of state changes in the call state of that context. Unsolicited notifications only appear on the control port, never on the application port.

Example: To set up a call on context 1 with unsolicited notifications enabled.

```
AT_OWANCALL=1,1,1      ( <- set up call )
OK

_OWANCALL: 1, 1        ( <- call is up now )

AT_OWANCALL=1,0,1      ( <- tear down call )
OK

_OWANCALL: 1, 0        ( <- call has torn down )
```

#### Defined values

<c>: The context corresponding to the cgdcont id.

<s>: Desired state.

- 0 Disconnect
- 1 Connected
- 2 Call setup in progress
- 3 Call Failed (only available at query command)

<u>: Enable (1) or disable (0) unsolicited notification of state changes for that context. If enabled the card will put unsolicited notifications to the NDIS AT port (and Application port – see FW release notes) of the format:

\_OWANCALL: <c>,<s>

**Author:** J. Schrijvers

**Creation Date:** Dec 2, 2009

**Option**

**Confidential:** This document is Option Confidential - it may not be duplicated, neither distributed externally without prior and written permission of Option nv.

**Version:** v007ext

**Page:** 4 of 8

## 2.2 Network Data “\_OWANDATA”

Command	Possible Response(s)
AT_OWANDATA=<c>	_OWANDATA: <c>, <ip>, <gw>, <dns1>, <dns2>, <nbns1>, <nbns2>, <csp> OK
AT_OWANDATA?	_OWANDATA: <c>, <ip>, <gw>, <dns1>, <dns2>, <nbns1>, <nbns2>, <csp> ... OK

### Description

This command is used with an active call ( set up using AT\_OWANCALL ) to get the IP details used for configuring the network interface.

The write command will just look up the IP details for that specific context and return nothing if the context is not active.

The query command will loop through all the contexts and display the IP details for the ones whose context is active.

### Defined values

<c>:            The context corresponding to the cgdcont id.

<ip>:           IP address

<gw>:           Gateway address

<dns1>:        First DNS server

<dns2>:        Second DNS server

<nbns1>:       First NBNS server

<nbns2>:       Second NBNS server

<csp>:           Connection Speed

**Author:** J. Schrijvers

**Creation Date:** Dec 2, 2009

**Option**

**Confidential:** This document is Option Confidential - it may not be duplicated, neither distributed externally without prior and written permission of Option nv.

**Version:** v007ext

**Page:** 5 of 8

## 2.3 PDP Context Authentication “\$QCPDPP”

Command	Possible Response(s)
AT\$QCPDPP=<cid>,<auth-type>,<password>,<username>	OK ERROR
AT\$QCPDPP?	\$QCPDPP: <cid>,<auth-type>,<password>,<username> ... OK

### Description

This command is intended to be used for products based on a Qualcomm chipset. This command is used to define the authentication parameters associated with a particular PDP context <cid>. <cid> corresponds to the id used in the CGDCONT command.

Note that the password and username parameters are mandatory with authentication types PAP and CHAP.

### Defined values

<cid> : The context corresponding to the cgdcont id. 1-16.

<n> : Authentication type

0: No Security

1: PAP

2: CHAP

<passw> : String value for entering password to be used in security handling

<user> : String value for entering username to be used in security handling

**Author:** J. Schrijvers

**Creation Date:** Dec 2, 2009

**Option Confidential:** This document is Option Confidential - it may not be duplicated, neither distributed externally without prior and written permission of Option nv.

**Version:** v007ext

**Page:** 6 of 8

## 2.4 PDP Context Authentication “\_OPDPP”

Command	Possible Response(s)
AT_OPDPP=<cid>,<auth-type>,<password>,<username>	OK ERROR
AT_OPDPP?	_OPDPP: <cid>,<auth-type>,<password>,<username> ... OK

### Description

This command is intended to be used for products based on a lcera chipset. This command is used to define the authentication parameters associated with a particular PDP context <cid>. <cid> corresponds to the id used in the CGDCONT command.

Note that the password and username parameters are mandatory with authentication types PAP and CHAP.

### Defined values

<cid> : The context corresponding to the cgdcont id. 1-16.

<n> : Authentication type  
0: No Security  
1: PAP  
2: CHAP

<passw> : String value for entering password to be used in security handling

<user> : String value for entering username to be used in security handling

**Author:** J. Schrijvers

**Creation Date:** Dec 2, 2009

**Option**

**Confidential:** This document is Option Confidential - it may not be duplicated, neither distributed externally without prior and written permission of Option nv.

**Version:** v007ext

**Page:** 7 of 8



### 3 SCENARIO

A connect scenario on an example network looks like:

```
-> Open Control port
AT+CGDCONT=1,"my.apn.here"
```

(Configure APN)

OK

```
AT$QCPDPP=1,1,"mypassword","myusername"
```

OK

(Configure username, password)

```
AT_OWANCALL=1,1,1
```

(Set up call for context 1 with unsolicited notifications enabled)

OK

```
_OWANCALL: 1, 1
```

(Call ready !)

```
AT_OWANDATA=1
```

```
_OWANDATA: 1, x.x.x.x, y.y.y.y, d1.d1.d1.d1, d2.d2.d2.d2,
n1.n1.n1.n1, n2.n2.n2.n2
```

(IP, gateway, dns1, dns2, nbns1, nbns2 settings)

OK

Using the OWANDATA data you then need to configure the Ethernet interface and then we're ready.

To disconnect the call:

```
AT_OWANCALL=1,0,1
```

(Disconnect context 1 )

OK

```
_OWANCALL: 1, 0
```

(Disconnected)

**Author:** J. Schrijvers

**Creation Date:** Dec 2, 2009

**Option**

**Confidential:** This document is Option Confidential - it may not be duplicated, neither distributed externally without prior and written permission of Option nv.

**Version:** v007ext

**Page:** 8 of 8